

Snappitz Clamp Chart

Chart 1.1 -IPS- Unit O.D.'s

IPS Pipe Size	INSULATION THICKNESS			
	1/2"	1"	1-1/2"	2"
1/2"	2"	2-7/8"	4"	5"
3/4"	2-3/8"	2-7/8"	4"	5"
1"	2-3/8"	3-1/2"	4-1/2"	5-5/8"
1-1/4"	2-7/8"	3-1/2"	5"	5-5/8"
1-1/2"	2-7/8"	4"	5"	6-5/8"
2"	3-1/2"	4-1/2"	5-5/8"	6-5/8"
2-1/2"	4-1/2"	5-5/8"	6-5/8"	7-5/8"
3"	4-1/2"	5-5/8"	6-5/8"	7-5/8"
3-1/2"	5"	6-5/8"	7-5/8"	8-5/8"
4"	5-5/8"	6-5/8"	7-5/8"	8-5/8"
5"	6-5/8"	7-5/8"	8-5/8"	9-5/8"
6"	7-5/8"	8-5/8"	9-5/8"	10-5/8"
8"	9-5/8"	10-5/8"	11-5/8"	12-3/4"
10"	11-5/8"	12-3/4"	13-3/4"	15"
12"	13-3/4"	15"	16"	17"

Chart 1.2 -Copper Tube- Unit O.D.'s

Copper Tube Pipe Size	INSULATION THICKNESS			
	1/2"	1"	1-1/2"	2"
5/8"	2"	2-7/8"	3-1/2"	4-1/2"
7/8"	2"	2-7/8"	4"	5"
1-1/8"	2-3/8"	2-7/8"	4"	5"
1-3/8"	2-3/8"	3-1/2"	4-1/2"	5-5/8"
1-5/8"	2-7/8"	3-1/2"	5"	5-5/8"
2-1/8"	3-1/2"	4"	5"	6-5/8"
2-5/8"	3-1/2"	4-1/2"	5-5/8"	6-5/8"
3-1/8"	4"	5"	6-5/8"	7-5/8"
4-1/8"	5"	6-5/8"	7-5/8"	8-5/8"
5-1/8"	6-5/8"	7-5/8"	8-5/8"	9-5/8"
6-1/8"	7-5/8"	8-5/8"	9-5/8"	10-5/8"

Chart 2.1 -IPS- Hanger Size Chart

IPS Pipe Size	INSULATION THICKNESS			
	1/2"	1"	1-1/2"	2"
1/2"	1-1/2"	2-1/2"	3-1/2"	4-1/2"
3/4"	2"	2-1/2"	3-1/2"	4-1/2"
1"	2"	3"	4"	5"
1-1/4"	2-1/2"	3"	4-1/2"	5"
1-1/2"	2-1/2"	3-1/2"	4-1/2"	6"
2"	3"	4"	5"	6"
2-1/2"	4"	5"	6"	7"
3"	4"	5"	6"	7"
3-1/2"	4-1/2"	6"	7"	8"
4"	5"	6"	7"	8"
5"	6"	7"	8"	9"
6"	7"	8"	9"	10"
8"	9"	10"	11"	12"
10"	11"	12"	14"	15"
12"	14"	15"	16"	17"

Chart 2.2 -Copper Tube- Hanger Size Chart

Copper Tube Pipe Size	INSULATION THICKNESS			
	1/2"	1"	1-1/2"	2"
5/8"	1-1/2"	2-1/2"	3"	4"
7/8"	1-1/2"	2-1/2"	3-1/2"	4-1/2"
1-1/8"	2"	2-1/2"	3-1/2"	4-1/2"
1-3/8"	2"	3"	4"	5"
1-5/8"	2-1/2"	3"	4-1/2"	5"
2-1/8"	3"	3-1/2"	4-1/2"	6"
2-5/8"	3"	4"	5"	6"
3-1/8"	3-1/2"	4-1/2"	6"	7"
4-1/8"	4-1/2"	6"	7"	8"
5-1/8"	6"	7"	8"	9"
6-1/8"	7"	8"	9"	10"